

Lamptabell 1967

BULB DATA CHART 1967

Function	Bulb No.	C/P	Body Style
Ash Tray - Front	1445	.7	All
Back Up (In Tail Lamp)	1195	50	All Except 69347
Back Up	1156	32	69347
Console Lamp	57	2	68347-49-67-69347 (When Ord.)
Cornering Lamp	1195	50	All
Courtesy Lamp - Rear Quarter	90	6	68069-68169-68247-49- 68349-68369-69347
Courtesy Lamp - Console	212/212-1	6	68347-49-67-69347
Courtesy Lamp - Instrument Panel	89	6	All
Courtesy Lamp - Rear Door	212/212-1	6	68069-68169-69723-69733
Courtesy Lamp - Rear Quarter Armrest	212/212-1	6	68367
Cruise Control Dial	1445	.7	All (When Ord.)
Cruise Control (Lock In Indicator)	161	1	All (When Ord.)
Generator Tell-Tale	161	1	All
Glove Compartment	1895	2	All
Headlamp-Lower or Inner	L4001	37.5 Watts	All
Headlamp Upper or Outer	L4002	37.5 Watts 55.0 Watts	All
Headlamp Switch	1816	3	All
Heater or A/C Control	1816	3	All
High Beam Indicator	161	1	All
Ignition Lock	1445	.7	All
License Lamp	67	4	All
Low Brake Tell-Tale	161	1	All
Low Oil Tell-Tale	161	1	All
Map Lamp	89	6	All
Panel Lamps	168	3	All
Park-Signal Lamp	1157A	32/4	All Except 693
	1157NA	32/4	693
Radio Dial Lamp	1816	3	All (When Ord.)
*Radio AM-FM Band Indicators	250	.5	All (When Ord.)
*Radio AM-FM Band and Stereo Indicators	2181D	.4	All Except 69723-69733-69890 (When Ord.)
*Radio - Rear Control Indicator	250	1	69723-69733 (When Ord.)
Rear Seat Warmer Indicator	1895	2	69723-69733 (When Ord.)
Spot Lamp	90	6	69733
Spot-Reading	1004	15	69723-69733-68169
Stop, Tail & Signal	1157	32/4	All
Tray, Seat Back	212/212-1	6	68169
Trunk Compartment	89	6	All Exc. 69890 (When Ord.)
Trunk Lid Tell-Tale	161	1	All Exc. 69890 (When Ord.)
Turn Signal Indicator	1445	1	All Except 693
	1895	2	693
Warning Lamp-Front Door	212/212-1	6	68347-49-67-69-69347 68069-68169
Warning Lamp-Rear Door	212/212-1	6	68169-68069-68347-68369
Windshield Wiper Switch	1895	2	All